## **INSTALLATION**

hand or object. Ultra loud 100dB alarm Self-adjusting sensitivity with manual high and low option

Mount alarm by hanging on door knob and alarm will sound if the opposite handle is touched by







( I-YEAR WARRANTY



Security Alarm

elbneH eldizgelloJ

1. Swing hanger to extended position.

For all wood and non-metallic doors

Uses 9-volt alkaline battery (not included)

Hang alarm on door knob and stop the swinging motion if necessary. 3. Set upper switch to low.

3 position switch - test for installation, off and alarm

- 4. Switch unit to test. Wait approximately one minute before testing.
- 5. Alarm is now ready for test. Touching door knob/handle will activate LED. If not, switch upper switch to high and repeat steps 4-5. **Note:** Door Knob Alarm is designed for all wood and non-metallic doors with metallic door knob handle. It can be used on wood and non-metallic doors with metal door frames too. But the door latch mechanism must be insulated from the door frame. This can be done simply by putting a plastic sheet between the door latch mechanism and the door frame before closing the door.
- 6. Switch unit to alarm. Wait approximately one minute and the unit is ready.



0408 SR4330



## LIMITED WARRANTY

The product you have purchased is guaranteed against defects in workmanship and materials for the period stated on the package. Warranties implied by law are subject to the same time period limitation. Some states do not allow limita-tions on how long an implied warranty lasts, so this time limi-tation may not apply to you. tation may not apply to you.

If the product fails due to a manufacturing defect during nor-mal use, return the product and dated sales receipt to the store where purchased for replacement OR send the product and the dated sales receipt to:

Lamson & Sessions 25701 Science Park Drive Cleveland, OH 44122 USA Attn: LHP Customer Service

Not Covered - Batteries, light bulbs, and other expendable items are not covered by this warranty. Repair service, adjust-ment and calibration due to misuse, abuse or negligence are not covered by this warranty. Unauthorized service or modifi-cation of the product or of any furnished components will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, set-up time, loss of use, postage, unauthorized service, or other products used in conjunction with, but are not supplied by, Lamson & Sessions.

Sessions.

All requests for replacement must include a **dated sales** receipt (copies accepted). LAMSON & SESSIONS IS NOT LIABLE FOR LOST PROFITS, INDIRECT, SPECIAL, EXEMPLARY, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITA-TION ANY SUCH DAMAGES DUE TO IMPROPER WIRING OR MIS-USE OF THE PRODUCT. As some states do not allow the exclu-sion or limitation of incidental or consequential damages, the above limitation and exclusion may not apply to you.

## ALSO AVAILABLE FROM CARLON:

- Extend-A-Chime<sup>®</sup> lets you hear your exis remote areas of your home or yard Plug-in and Battery Doorbells and Chimes On/Off Remote Switches - lets you hear your existing wired doorbell in

- Touch and Automatic Lighting Controls •

## arlon®

25701 Science Park Drive Cleveland, Ohio 44122 www.lamson-sessions.com

Made in China © 2004 LAMSON © 2004 LAMSON & SESSIONS 0408 IS132